



Toll Free (800) 676-6307  
[www.con-cretewerks.com](http://www.con-cretewerks.com)

Directions for use will vary with product use.

**SURFACE PREPARATION:** Concrete surface must be clean and free of all contaminants and water. Do not apply if rain is

forecast within 24 hours. If moisture is present or if the surface is not clean and free of all contaminants, this product may not be able to fix the original issue.

Substrate temperature must be no less than 40 degrees F and not exceed 80 degrees F. If applied outside these limits this product may not achieve adequate film formation and may have excessive air entrapment, bubbles, blushing or hazing.

**MIXING:** Stir well before using. Material may separate during long term storage.

**APPLICATION:** Apply using a 3/8" – 1/2" nap roller cover heavily using slow, long even uniform strokes at approximately 100-200 square feet per gallon depending on porosity and texture of substrate to allow existing coating adequate time to reemulsify. An acetone resistant sprayer may be used as well. Applying too thin may yield less than required results.

Allow Rejuvenate to dry for 24 hours for light traffic and at least 48 hours for heavy traffic. If applying two coats, wait approximately 4 – 6 hours between coats.

**PLEASE NOTE:** It is always recommended to test the product in a small, inconspicuous area (on the same concrete substrate) for desired results prior to application. Coverage rates may vary for all coatings and substrates depending on porosity, density, texture etc. If applying by spray method, extended coverage rates may be achieved, but be aware that less material will be applied and inadequate film formation or performance expectations may be limited.

**FOR PROFESSIONAL USE ONLY!**